
Formulation of metal compounds Eurometaux 2.2a.v2.1 - Formulation of metal compounds in plastics and			
Eurometaux 2.2a.v2.1 - Formulation of metal compounds in plastics and			
Eurometaux 2.2a.v2.1 - Formulation of metal compounds in plastics and			
rubber industry sector			
Eurometaux 2.2b.v2.1 - Formulation of metal compounds in pigments, paints and coating industry sector			
and coating industry sector Eurometaux 2.2c.v2.1 - Formulation of metal compounds in other than plastics			
and paint sectors			
Limitations of coverage compared to ERC relate to:			
User groups: User groups include: mixing and blending of metal compounds into preparations. The coverage of the main industries are pigments, paints, coatings and plastics, rubber. Other industries covered (but to a lesser extent are catalysts, textiles, water treatment chemicals, refractory.			
Catalysts Diamonto points positions			
Pigments, paints, coatings Plastics			
■ Plating			
Rubber			
■ Textiles			
■ Water treatment chemicals			
(leeg)			
Refractory			
Substance groups or functions: Release defaults are derived from measured emissions. Metal representativeness of background data: Lead Cobalt Chromium Boron Barium			
= Antimony			
Metal (compound) is defined here in a broad sense. The definition includes alkali metals, alkaline earth metals, transition metals, post-transition metals, metalloids and their compounds but excludes non-metals, halogens, noble gases and metallo-organic compounds. SPERC valid for metals with solid water partition coefficient for suspended matter between 2,500 L/kg and 300,000 L/kg. Types of products: Metal compounds (use as flame retardant synergist, stabiliser, pigment, anticorrosive agent, etc)			



	 efficiency within 2 hours at 2g/L, membrane electrolysis, electrochemic precipitation, pH 4-10, >99% removal efficiency) Reverse osmosis: extensively used for the removal of dissolved metals lon exchange: final cleaning step in the removal of heavy metal from process wastewater (e.g. 90% removal efficiency for clinoptinolite and 100% removal efficiency for synthetic zeolite) Biological treatment plant 			
	Eurometaux 2.2a.v2.1 (plastics and rubber)	98% (82.5%	% - 99.9%)	Based on data from 6 sites.
	Eurometaux 2.2b.v2.1 (paints and coatings)	91% (90%	- 93%)	Based on data from 3 sites.
	Eurometaux 2.2c.v2.1 (other sectors)	2.2c.v2.1 No RMMs		
				vented. If the metal content al recovery/recycling might
Substance use rate	Assessment defaults as substance use rate.	set by ERC.	It is recommo	ended to use a realistic
Days emitting	Default number of emission days are derived from a multi-metal background database of measured site-specific release factors collected under the former Directive of New and Existing Substances and REACH 2010 registration dossiers.			
	Eurometaux 2.2a.v2.1 (plastics and rubber)	47 days/year		ercentile of reported site- mber of emission days for
	Eurometaux 2.2b.v2.1 (paints and coatings)	150 days/year	The 10th p	ercentile of reported site- mber of emission days for
	Eurometaux 2.2c.v2.1 (other sectors)	67 days/year	The 10th p	ercentile of reported site- mber of emission days for
Integrated release factors (air, water, soil)	Default release factors are derived from a multi-metal background database of measured site-specific release factors collected from peer-reviewed EU Risk Assessment Reports under the former Directive of New and Existing Substances and REACH 2010 registration dossiers.			
	Air			
	Eurometaux 2.2a.v2.1 (plastics and rubber)	0.005% (aft on-site RMI		percentile of reported ecific release factors to air ites.
	Eurometaux 2.2b.v2.1 (paints and coatings)	0.005% (aft on-site RMI	ter The 90 th M) site-spe	percentile of reported ecific release factors to per 11 sites.
	Eurometaux 2.2c.v2.1 (other sectors)	0.01% (afte on-site RM	er The 90 th M) site-spe	percentile of reported ecific release factors to or 6 sites.
	Water Eurometaux 2.2a.v2.1	0.0002%	The 90t	h percentile of reported

	(plactice and milet a)	/often c:= =!4 -	aita anacifia valance factore to	
	(plastics and rubber)	(after on-site	site-specific release factors to	
		STP)	wastewater for 35 sites.	
	Eurometaux 2.2b.v2.1	0.01% (after	The 90th percentile of reported	
	(paints and coatings)	on-site STP)	site-specific release factors to	
		,	wastewater for 16 sites.	
	Eurometaux 2.2c.v2.1	2% (before	The 90th percentile of reported	
	(other sectors)	on-site STP)	site-specific release factors to	
		,	wastewater for 14 sites.	
	Soil	a la		
	Not applicable to local so	cale		
	Waste			
	The 90 th	percentile of re	ported site-specific release factors to	
			stream user sites covering zinc,	
	nickel, lead, antimony			
Optional risk	For iteration purposes (if	SPERC default	release factors do not demonstrate	
management	safe use), it is recommended to measure/monitor the air and/or water releases			
measures for	as a first refinement step. In case further iterations are required, a combination			
iteration	of multiple obligatory on-site measures can be considered.			
Narrative	Since metal SPERCs are based on measured data at end-of-pipe on-site, all			
description	indicated PROCs are integrated in the release fractions from raw materials			
	handling to cleaning and			
			gement measures and solid or liquid	
			g processes should be disposed of	
	separately to hazardous waste incineration plants or hazardous waste landfills			
	as hazardous waste.			
Scaling	If a site does not comply with the conditions stipulated in the SPERC, it is			
	recommended to monitor the air and water releases and apply the Metals DU			
	scaling tool in order to perform a site-specific assessment. Each site can			
	evaluate whether he works inside the boundaries set by the ES through			
	scaling. The Metal EUSES calculator for DUs is freely available to metal			
	industry DUs and can be downloaded from http://www.arche-consulting-be/Metal-CSA-toolbox/du-scaling-tool			
	consulting.be/Metal-CSA-toolbox/du-scaling-tool.			

Determinant Label ¹	Quali-/ Quanti- tative ²	Value ³	Description of Value ⁴
On site treatment of wastewater	Qual	Chemical precipitation or sedimentation or filtration or electrolysis or reverse osmosis or ion exchange or biological treatment	Following IPPC-BREF note document, the treatment methods are very much dependent on the specific processes and the metals involved. Direct water emissions should be reduced by implementing one or more of the following RMMs: • Chemical precipitation: used primarily to remove the metal ions (e.g. Ca(OH)2, pH 11 precipitation: >99% removal efficiency; Fe(OH)3, pH 11: 96% removal efficiency) • Sedimentation (e.g. Na2S, pH 11, >99% removal efficiency) • Filtration: used as final clarification step (e.g.

			ultrafiltration, pH 5.1: 93% removal efficiency, nanofiltration: 97% removal efficiency, reverse osmosis, pH 4-11: 99% removal efficiency) "• Electrolysis: for low metal concentration (e.g. electrodialysis: 13% removal efficiency within 2 hours at 2g/L, membrane electrolysis, electrochemical precipitation, pH 4-10, >99% removal efficiency) • Reverse osmosis: extensively used for the removal of dissolved metals lon exchange: final cleaning step in the removal of heavy metal from process wastewater (e.g. 90% removal efficiency for clinoptinolite and 100% removal efficiency for synthetic zeolite) More information can be found in EC (2001), Integrated Pollution Prevention and Control (IPCC): reference document on Best Available Techniques in the Non Ferrous Metals Industries.
On site treatment of off-air	Qual	Electrostatic precipitator or wet electrostatic precipitator or cyclones or fabric/bag filter or ceramic/metal mesh filter or wet scrubber	Direct air emissions should be reduced by implementing one or more of the following RMMs: Electrostatic precipitators using wide electrode spacing: 5 – 15 mg/Nm³ Wet electrostatic precipitators: < 5 mg/Nm³ Cyclones, but as primary collector: < 50 mg/Nm³ Fabric or bag filters: high efficiency in controlling fine particulate (melting): achieve emission values < 5 mg/Nm³. Membrane filtration techniques can achieve < 1 mg/Nm³ Ceramic and metal mesh filters. PM10 particles are removed: 0.1 mg/Nm³ Wet scrubbers: < 4 mg/Nm Fugitive emissions should be reduced from material storage and handling, reactors or furnaces and from material transfer points by following hierarchical measures: process optimization and minimization of emissions, sealed reactors and furnaces, targeted fume collection.